



Chakra lamp – User manual



Thank you for your trust,



Your purchase supports the development of
Egeiro's vision towards a more sustainable and
responsible way of manufacturing.

Damien Dando

Chakra lamp – User manual

1

Plug-in the USB cable into a USB port or a USB power supply and turn the lamp on/off with the white switch.




2

Brightness adjustment

While the lamp is on, do a **long press** (>1s.) on the button. Some of the chakras will light up in white to indicate the current brightness setting.

While chakras are light up in white, do several short press on that same button to adjust the brightness among the 4 following levels:



The mode and brightness level are automatically saved when the lamp is turned off or unplugged.



This memorization happens about 5 seconds after the last change of mode/intensity and do not require any particular action.

3

Change of mode

While the lamp is on, do a **short press** (<1s.) on the bouton. Some of the chakras will light up in white to indicate the current mode.

While chakras are light up in white, do several short press on that same button to chose one of the following modes:



For any help or question, feel free to contact Damien Dando via email (contact@egeiro.se) or phone (+46730935610).