


Mini LED Lamp – User manual



- 1** Plug-in the USB cable into a USB port or a USB power supply and turn the lamp on/off with the white switch.

- 2** While the lamp is on, do short press (less than 1 second) on the button to select one of the following color or mode:



- 3** Do a long press (more than 1 second) on the button to adjust the light intensity among the 4 different levels.

The color, mode and light intensity are automatically saved when the lamp is unplugged.

This memorization happens about 5 seconds after the last change of color/mode/intensity and do not require any particular action.

For any help or question, feel free to contact Damien Dando via email (contact@egeiro.se) or phone (+46730935610).